Amana®

IN STYLE.
ON BUDGET.
GO FIGURE.
DISH
Get the dish
on design from
THOMFILICIA

Yes.

That's the answer to the million dollar question: Can appliances really be stylish? Of course they can. And they should be. Your home is a reflection of your personality and your preferences, so why stop at framed photos and wall paint? We say enhance it all. So we did. Our refrigerators pop with color.

Our cooking appliances intensify your flair for flavor. Ultimately, we believe style should be shared. That's why Amana brand lines up good style with your budget. It's not about being elite and fancy. It is, however, about being you.

Keep it clean.

So clean, it shines. Forks, knives, plates, bowls and cups—give your hands a break and let the dishwasher tackle the dirty work. Cycles and options come aplenty with the space to match. So load up and walk away. There's certainly more you could be doing with your day.

A

Dishwashers

The pressure is on. With the MasterClean™ Plus wash system, a high water flow powerfully removes food from your dishes. Don't worry, they'll handle it just fine.

ADB1500AWS

Are you concerned about conservation? Do you want to do your part to reduce the use of our earth's resources?

Save water. Save energy. Save money. Help save the planet. All Amana® dishwashers are ENERGY STAR® qualified, so you will have less of an impact on the environment and still have clean dishes.

"AN IDEAL DOSE OF CLEAN"

TALL TUB INTERIOR

Handles more plates than a waitress during lunch hour. Our dishwashers feature a Tall Tub design, so go ahead, add that one last dish. Or pizza pan.

TIERED, REMOVABLE UPPER RACK

It really does come out! And as a result, you can finally wash that gigantic bowl, platter or vase. Leave the rack in, and the tiered design makes room for all your cups and containers. And it still leaves room for bigger items below.

SANITIZE OPTION

Bacteria be gone. Certified by NSF International, the Sanitize option removes 99.999% of food soil bacteria. You can be sure that the whole load, from baby bottles to butter knives, is clean and sanitized.

DELAY START

Wash dishes according to your schedule. Program the dishwasher to run during off-peak energy hours or when you're away from the kitchen.



TWICE AS NICE™ SILVERWARE BASKETS

Pick a place, any place. That's the motto of these two silverware baskets. Whether you put them in the door, or in either of the racks, all your utensils stay in one spot—not all over the place—for an ideal dose of clean.

Q **How many dishes can you load into your current dishwasher? Do you hate having to hand wash those pesky dishes that just won't fit?**

Amana® dishwashers certainly aren't short on space. A Tall Tub design holds more dishes than a standard-sized dishwasher. Plus, it's just enough room for that odd-shaped item you'd rather not wash by hand.

ADB1500AW
Tall Tub Interior
W / Q / B / S

ADB2500AW
Tall Tub Interior
W / Q / B / S



ADB3500AW
Tall Tub Interior
W / B / S

DISHWASHERS

	ADB1500AW	ADB2500AW	ADB3500AW
Tall Tub Interior	White Plastic	White Plastic	Stainless Steel
ENERGY STAR® Qualified	●	●	●
MasterClean™ Plus Wash System	●	●	●
Rack Type	Vinyl	Nylon	Nylon
Twice as Nice™ Silverware Baskets with Covers	2	2	2
Number of Cycles	3	5	5
Heavy Wash	●	●	●
Normal Wash	●	●	●
Quick Wash	●	●	●
Rinse Only		●	●
Auto Wash		●	●
Number of Options	3	5	5
High Temperature Wash	●	●	●
Sanitize		●	●
Heated Dry	●	●	●
2-, 4- or 6-Hour Delay Start	●	●	●
Control Lockout		●	●
One-Touch Memory	●	●	●
Tiered, Removable Upper Rack	●	●	●
Hi-Side Lower Rack with 2 Cup Shelves		●	●
Rinse Aid Dispenser	●	●	●
Low Rinse Aid Indicator	●	●	●
Touchmatic™ Electronic Controls	●	●	●
Cycle Status Indicator		●	●
Stainless Steel Hard Food Disposer	●	●	●
Self-Cleaning, Fine Mesh Filtration	●	●	●
Sound Package	SofSound™ I	SofSound™ II	SofSound™ III
Colors	W / Q / B / S	W / Q / B / S	W / B / S

COLORS

W White
Q Bisque
B Black
S Stainless Steel

These products meet the ENERGY STAR® guidelines for energy efficiency.

NOTE: Trim kits and side mount kits are included with all new Amana® dishwashers.

For more information go to Amana.com

Get loaded!

Believe it or not, there is an art to loading the dishwasher. We liken it to finger painting, rather than something Van Gogh would craft. So whether it's knowing the right spot for a gigantic frying pan, a little plastic bowl or everything in between—with a little direction, it's really just that easy.





Top Rack

Keep plastic on the top rack with cups and mugs, plus your smaller bowls and plates.

Utensil Basket

When it comes to utensils, it's always a good idea to load knives with the handles up. Alternate forks and spoons so they don't nest together.



Bottom Rack

Save the bottom rack for dinner plates, mixing bowls, pots and pans. Face it all toward the center for an effective clean.

Be Squeaky Clean

Don't forget the detergent. Choose one designed for use in a dishwasher and make sure that it's fresh for optimum results.

Earn a Spotless Reputation

Say bye-bye to spots and film on your dishes. Regular use of Rinse Aid improves drying performance and reduces spotting. Check your Rinse Aid dispenser monthly and refill as needed for sparkling results.

DISHWASHER ACCESSORIES

For a complete listing of accessories available for Amana® dishwashers, please visit ApplianceAccessories.com

Small Items Basket

3370993RB

There's no need to fish for small items in the bottom of the dishwasher. Control the mayhem with this basket. From lids to teaspoons, it keeps your littlest dishes in one place from cycle start to finish.

All-Purpose Appliance Cleaner

31682

Grease and grime, be gone! This cleaner cuts through the dirty stuff. Not only is it safe for your appliances—even the insides—you can use it on tubs and sinks, too.

Dishwasher Installation Kit

8212488RC

Get hooked up with this all-inclusive kit. Tape, a strain relief bracket, wire caps and 3/8" brass compression fitting with an elbow and tee are all there so you can get washing right away.

Water Supply Line

4396897RW

Make sure your dishwasher is getting enough of its most essential ingredient. Check your hose every so often. If it needs to be replaced, this 6' braided hose is your best bet.

Stainless Steel Cleaner and Polish

31462

Keep it sleek with a cleaner that makes stainless steel surfaces bright and shiny. This non-abrasive formula works wonders on your appliances. And yes, you can use it on your sink and cookware, too.

Dishwasher Rack Repair Kit

White: **4396838RC**
Grey: **4396840RC**

Paint it perfect with this kit. Easily cover small cuts or exposed portions of the rack. Plus, this kit includes rack tip tines for an appearance that looks like new.

Glisten™ Dishwasher Cleaner

4319102

Even the dishwasher needs a little cleaning. Natural food acids help remove soap scum and stains while minimizing the discoloration caused by water impurities. Use it monthly for best results.

Amana
Washing
Drying
ycles
Quick Wash
Rinse Only
2
4
6
DELAY Hours
START/ Resume
CANCEL

Thom's StyleFile

I love this **kitchen** because it screams **fun** with a capital "F"

The colors are amazing, and the layout takes total advantage of the space. It's perfect—not just for preparing food, but for eating, hanging out and entertaining, too. That's really what great kitchens are all about.

Bold red cabinets and a beautiful backsplash turn an otherwise standard kitchen into a young, fresh, cool space.

Notice the great light fixtures and artwork, which also bring some style into the space.

GET *LINKED* FOR MORE LINGO

Discover new style ideas: Amana.com

DISHWASHER GLOSSARY

Auto Wash
Lets the dishwasher sensors evaluate the current load and configure the optimal wash cycle.

Control Lockout
Locks controls so little fingers can't turn on the dishwasher.

Cycle Status Indicator
A quick look gives you the low-down. See which stage the cleaning process is in; washing, drying, clean or sanitized.

Delay Start
Wash dishes according to your schedule. Program the dishwasher to run during off-peak energy use hours or when you're away from the kitchen.

ENERGY STAR® Qualified
Save money while conserving energy. These dishwashers meet the guidelines for energy efficiency.

Heated Dry
An internal heater accelerates the drying process, removing excess moisture so you can forgo the dish towel.

Hi-Side Lower Rack with Two Cup Shelves
Load mugs, tea cups or other items on the cup shelves, or rest larger or flat items, like baking sheets, against the higher side of the rack.

Low Rinse Aid Indicator
A friendly reminder that your dispenser needs to be refilled.

MasterClean™ Plus Wash System
Easily clean items on both racks. Powered by a 1/3-HP motor, the MasterClean™ Plus wash system combines high water pressure and high water flow to powerfully remove food from your dishes.

One-Touch Memory
Press "start" and the dishwasher automatically selects the last-used cycle.

Quick Wash Cycle
Rapidly clean lightly soiled items like glassware.

Rinse Aid Dispenser
Automatically adds a measured amount during the wash cycle, reducing the potential for spots on your dishes. And giving you one less thing to worry about.

Rinse Only Cycle
If they're just dusty, this is the only cycle you'll need. It forgoes detergent, using water to freshen things up.

Sanitize Option
Certified by NSF International, this cycle boosts water temperature during the wash cycle to remove 99.999% of food soil bacteria.

Self-Cleaning, Fine Mesh Filtration
Say "so long" to prerinsing your dishes. The wash water is filtered through a very fine mesh to keep food particles from redepositing on your dishes.

SofSound™ Sound Packages
Provides insulation for increased quietness. Now, you really can run the dishwasher if you're watching television or a movie.

Tall Tub Interior
Holds more dishes and provides more room for items that are too big to fit in a standard dishwasher tub.

Tiered, Removable Upper Rack
Makes room for large items throughout the dishwasher. Or, remove the upper rack entirely to wash large items in the lower rack.

Touchmatic™ Electronic Controls
Cycle selection just got easier with a sleek, refined console design. These controls are at home in any kitchen.

Twice as Nice™ Silverware Baskets
Wash more utensils at once. Plus, you can move these baskets from the door to either rack for increased loading flexibility.

DISHWASHER DIMENSIONS

DISHWASHERS

MODEL	Height* (A)	Width (B)	Depth Including Door (C)	Depth Excluding Door (D)
ADB1500AW	33½" – 35¼"	23⅞"	23⅞"	19½"
ADB2500AW	33½" – 35¼"	23⅞"	23⅞"	19½"
ADB3500AW	33½" – 35¼"	23⅞"	23⅞"	19½"

* Height without top trim strip is 33-1/2" minimum and 35-1/4" maximum.
Height with top trim strip is 33-3/4" minimum and 35-1/4" maximum.



FRONT VIEW



SIDE VIEW

Limited Warranty:

For one (1) year from the original retail purchase date any part that fails in normal home use will be repaired or replaced free of charge. Refer to the Use and Care Guide for warranty details.

Need Service?

See the troubleshooting section in your Use and Care Guide, call the dealer from whom your appliance was purchased, or call, Maytag Services LLC Customer Assistance at: **1-866-616-2664 (U.S.A.) or 1-800-688-2002 (Canada)** to locate an authorized servicer.

®Registered trademark/™Trademark of Maytag Corporation or its related companies. ®2009. All rights reserved. All other trademarks are owned by their respective companies. Form No. AAXL048. Printed in the U.S.A. 1/09.